
OUTDOOR BOTTLE FILLER USER GUIDE

FREE STANDING VERSION

Manual, non-refrigerated

DGM-BC



030099-731 DGM-BC Page 1/8

SECTION 1 – SAFETY INFORMATION

BEFORE YOU START USING THIS BOTTLE FILLER, PLEASE READ THE FOLLOWING INSTRUCTION CAREFULLY.

NOTE: All bottle fillers should be sanitized prior to first use. The appliance is suitable for outdoor use in commercial & industrial locations.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by the person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

Installation and servicing of the water dispenser should be carried out by an authorized employee.

OASIS will not be responsible for any injury, loss or damage of any kind sustained as a result of misuse of the water dispenser.



WARNING: To avoid hazard due to instability of the appliance it must be fixed according instructions.

SECTION 2 – WATER CIRCUIT

Water circuit elements:

FITTING FLOOM TUDE /TUDE 1/ "		
FITTING, ELBOW TUBE/TUBE 1/4"	-	2
SCREW – M4x12 socket	○ 3 mm	4
WASHER – M4 serrated	-	4
CARTRIDGE HOLDER	-	1
CARTRIDGE US (ADA)	-	1
CARTRIDGE EUR (WRAS)		
NUT – M4 flanged	○ 7 mm	3
PUSH BUTTON	-	1
BUTTON ADAPTER	-	1
FITTING, ELBOW STEM/TUBE 1/4"	-	1
FITTING, ¾"BSP/TUBE ¼"	-	1
NUT – G ¾"	○ 36 mm	1
WATER OUTLET SLEEVE	-	1
PEARLATOR	1	1
WATER OUTLET	○ 15 mm	1
DRAIN PLUG 1 1/4" NPSL	-	1
GASKET	-	1
NUT – 1 ¼" NPSL	O 2 1/16"	1
¼" TUBING	-	5 ft
	SCREW – M4x12 socket WASHER – M4 serrated CARTRIDGE HOLDER CARTRIDGE US (ADA) CARTRIDGE EUR (WRAS) NUT – M4 flanged PUSH BUTTON BUTTON ADAPTER FITTING, ELBOW STEM/TUBE ¼" FITTING, ¾"BSP/TUBE ¼" NUT – G¾" WATER OUTLET SLEEVE PEARLATOR WATER OUTLET DRAIN PLUG 1¼" NPSL GASKET NUT – 1¼" NPSL ¼" TUBING	SCREW – M4x12 socket WASHER – M4 serrated CARTRIDGE HOLDER CARTRIDGE US (ADA) CARTRIDGE EUR (WRAS) NUT – M4 flanged PUSH BUTTON BUTTON ADAPTER FITTING, ELBOW STEM/TUBE ¼" FITTING, ¾"BSP/TUBE ¼" NUT – G¾" WATER OUTLET SLEEVE PEARLATOR WATER OUTLET DRAIN PLUG 1 ¼" NPSL GASKET NUT – 1 ¼" NPSL CARTRIDGE US (ADA) - COMMENT OF THE METHOD ADAPTER -

^{*} Cartridge 029967-005 is used in models DGM-BC-___-US Cartridge 029967-006 is used in models DGM-BC-___

030099-731 DGM-BC Page 2/8




Fig. 1 – Water circuit elements

030099-731 DGM-BC Page 3/8

SECTION 3 – OVERALL DIMENSIONS

NOTE: Dimensions in brackets [] are in milimeters. Unit weight is 32,1 kg [70,7 lb]




Fig. 2 – Front & Side view

030099-731 DGM-BC Page 4/8




Fig. 3 – Bottom view

SECTION 4 – UNIT INSTALLATION

- 1. Inspect the carton and bottle filler for evidence of rough handling and concealed damage. Damage claims should be filed with the carrier.
- 2. Packaging should include following elements:

POS:	DESCRIPTION:	TOOL SIZE:	QTY:
1	COLUMN ASSEMBLY	-	1
2	ALCOVE ASSEMBLY	-	1
3	LOWER BACK PANEL	-	1
4	UPPER BACK PANEL	-	1
5	AESTHETIC RING	-	1
6	SCREW - M5x10 w/ torx drive	T25	14
7	SCREW - 3/8"x1,0" hexagonal	O 9/16"	2
8	NUT - 3/8" hexagonal	○ 9/16"	4
9	NUT – M4 flanged	○ 7 mm	6
10	WASHER - M5	-	2
11	¼" TUBING	-	5 ft
12	INSTRUCTIONS	-	1

030099-731 DGM-BC Page 5/8




Fig. 4 - Components

3. Slot aesthetic ring [5] onto the column assembly [1] and secure into position with fasteners [6,9,10].

It is recommended to fully tighten fasteners after alcove assembly is placed onto the column assembly (see step 4).




Fig. 5 – Aesthetic ring assembly

030099-731 DGM-BC Page 6/8

4. Place alcove assembly [2] onto the column assembly [1] with help of three guiding pins. Secure in place with screws [7] and nuts [8].




Fig.6 – Alcove assembly

5. Remove plugs from button assembly inlet & outlet and water outlet inlet.

Connect ¼" tube to make water circuit connections. See section 2 for reference.

Water drain installation and pressure regulator are not provided by Oasis and are to be installed according to local plumbing code. This outdoor bottle filler is designed to be operated at a water supply line pressure up to 100 PSI (690 kPa). A pressure regulator must be installed in front of the unit's water inlet if the pressure (including any possible pressure spikes) could exceed 100 PSI (690 kPa).

030099-731 DGM-BC Page 7/8

6. Install whole unit to the ground using 3/8" (6 places) or ½" anchors (4 places).

See Fig.3 for reference. Anchors are not included. This bottle filler is to be mounted on a smooth, flat, finished surface with adequate support structure.

Oasis can provide optional anchor assembly that can be delivered together with the unit.




Fig.7 – Optional anchor assembly

7. Install back panels [3,4] using screws [6]. Use two bottom screws to position lower back panel.




Fig.8 – Lower back panel positioning screws

030099-731 DGM-BC Page 8/8

P/N 030099-731 Rev Orig, Date: 07/2024

© 2024 LVD Acquisition, LLC

Oasis, Aqua Pointe, Versacooler and VersaFiller are registered trademarks of LVD Acquisition, LLC dba Oasis International



030099-731 DGM-BC Page 9/8